CRAFTSMAN®

PARTS LIST FOR 12 PC INCH BOX END WRENCH SET #33230

Congratulations on your purchase of a quality **CRAFTSMAN** Tool Set.
Should you have any questions about the tools you've just purchased, save some time and call our toll-free Customer Service Number which is **1-800-832-7494.**
We are open Monday through Friday from 8:00 a.m. to 4:30 p.m. Eastern Standard-Time.

CAT. NO.	DESCRIPTION		DRIVE SIZE
43919	1/4 x 5/16"	BOX END WRENCH INCH	
43922	3/8 x 7/16"	BOX END WRENCH INCH	
43921	7/16 x 1/2"	BOX END WRENCH INCH	
43923	1/2 x 9/16"	BOX END WRENCH INCH	
43924	9/16 x 5/8"	BOX END WRENCH INCH	
43925	19/32 x 25/32	BOX END WRENCH INCH	
43926	5/8 x 3/4"	BOX END WRENCH INCH	
43927	11/16 x 13/16"	BOX END WRENCH INCH	
43928	3/4 x 7/8"	BOX END WRENCH INCH	
43929	15/16 x 1"	BOX END WRENCH INCH	
43934	1-1/16 x 1-1/4"	BOX END WRENCH INCH	
43935	1-1/8 x 1-5/16"	BOX END WRENCH INCH	

CRAFTSMAN HAND TOOL FULL WARRANTY

If any Craftsman Hand Tool ever fails to give complete satisfaction, return it to any Sears store or other Craftsman Outlet in the United States for free repair or replacement. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

SEARS, ROEBUCK AND COMPANY, HOFFMAN ESTATES, IL 60179